



**POWER
WIPES®**

Dreumex Disinfectant & Cleaning Wipes (blue)
Blue wet wipes for disinfection and cleaning of surfaces,
especially in the food industry.



Product Properties

- blue, lint-free, tear-resistant wipes
- solution with tartaric acid
- PT2 and PT4 authorised
- bactericidal, yeasticidal and virucidal activity against enveloped viruses
- perfume- and colorant-free

Application Area

Dreumex Disinfectant & Cleaning Wipes (blue) are ready-to-use, lint-free wipes for disinfection and cleaning of surfaces in a single step. Recommended for use in the food industry, hotels and restaurants.

Activity and Test Methods

Bacteria and Fungi	Test method	Conditions	Contact time
Bactericidal	EN 16615	with mechanical action, dirty conditions	2 minutes
Yeasticidal	EN 16615	with mechanical action, dirty conditions	2 minutes

Viruses	Test method	Conditions	Contact time
Virucidal activity against all enveloped viruses	EN 16615 (adapted)	with mechanical action, dirty conditions	2 minutes

Spectrum of Activity

Active against bacteria, yeasts and enveloped viruses in 2 minutes.

Application

Wipe surfaces until they are completely moistened and keep them moist during the entire contact time of 2 minutes. Let surfaces dry completely and dispose of the wipe after use. Under normal conditions of use, it is not necessary to wear gloves. Use only wipes that are sufficiently moist. Close the lid after use and keep the container tightly closed. Protect from frost. Not suitable for use on acid-sensitive materials and soft metals. For professional use only.

Product Description of the Soaking Solution

Free from alcohols, aldehydes, bleaching agents, chlorine and VOCs.

Composition of the Soaking Solution

Contains < 5% phosphates, anionic surfactants, non-ionic surfactants.
Disinfectants: sodium benzoate 0,4g/100ml, (+)- tartaric acid 0,4g/100ml.

Storage Instructions

Dreumex Disinfectant & Cleaning Wipes (blue) will keep at room temperature if stored unopened in the original packaging. The expiry date is indicated on each container.

Statutory Regulations

Dreumex Disinfectant & Cleaning Wipes (blue) are subject to the Regulation on Biocidal Products (EU) No 528/2012 as well as to the Regulation on Detergents (EC) No 648/2004.

UFI: MF30-00U1-7000-51JH

Authorisation Number: EU-0018737-0001

An EC Safety Data Sheet for Dreumex Disinfectant & Cleaning Wipes (blue) is available and can be downloaded from www.pgp-skincare.com.

Product Types

PT2 - Disinfectants not intended for direct application to humans or animals

PT4 - Food and feed area disinfection


First Aid

If inhaled: move to fresh air; seek medical attention if symptoms persist. If in eyes: rinse opened eye with running water for several minutes. If swallowed: consult a doctor if symptoms persist.




Use biocides safely. Always read label and product information before use.



Can with 170 wipes
Art. No. 14486001
 6 pieces



Bucket with 700 wipes
Art. No. 14486002
 4 pieces



**serious
hygiene**

Peter Greven Physioderm GmbH · Procter-&-Gamble-Straße 26 · D-53881 Euskirchen (Germany)
+49 (0) 2251 77617-30 · info@pgp-skincare.com · www.pgp-skincare.com

Our information and recommendations correspond to our current state of experience. They are not binding and do neither imply any warranty nor do they establish a contractual relationship. We reserve the right of modifications in line with technological progress and further development of our products. We request our customers to conduct their own tests on our products for fitness for purpose.